


CA-7003 AIR BELT SANDER



ITEM NO.	REF. NO.	DESCRIPTION
1N	BJ0001N	IDLE PULLEY BRACKET SUB ASSY
2	BJ0002	IDLE PULLEY SET (2N,2E,43)
2N	BJ0002N	IDLE PULLEY
2E	BJ0002E	BALL BEARING (2)
3	BJ0003	SPRING
4	BJ0004	FINGER PAD ASSY
5	BJ0005	HEXAGON SOCKET HEAD BOLT
5A	BJ0005A	CUP SPRING
6	BJ0006	HEXAGON SOCKET HEAD BOLT 5x12
7	BJ0007	GRINDING BELT (#100)
7A	BJ0007A	GRINDING BELT (#80)
8	BJ0008	HEXAGON SOCKET HEAD BOLT 6x16
8A	BJ0008A	WASHER
9	BJ0009	DRIVE PULLEY
10	BJ0010	FLAT SHOE
11	BJ0011	HEXAGON SOCKET HEAD BOLT 5x15
12	BJ0012	DUST COVER
13	BJ0013	GUARD BODY
14	BJ0014	TENSION BAR
15	BJ0015	SPRING
16	BJ0016	LEVER PIN
17	BJ0017	LEVER PIN
18	BJ0018	HOUSING
18A	BJ0018A	COVER
19	BJ0019	BALL BEARING
20	BJ0020	END PLATE B
21	BJ0021	SPACER 10x13x3
22	BJ0022	SUNK KEY 2x2.5x10
23	BJ0023	CAP

ITEM NO.	REF. NO.	DESCRIPTION
24	BJ0024	BALL BEARING
25	BJ0025	END PLATE A
26	BJ0026	CYLINDER
26A	BJ0026A	LEVER PIN 3x6
27	BJ0027	ROTOR BLADE (5pcs/set)
28	BJ0028	ROTOR
29	BJ0029	THROTTLE LEVER
30	BJ0030	LEVER PIN
31	BJ0031	VALVE BODY
32	BJ0032	O-RING
33	BJ0033	O-RING
34	BJ0034	O-RING
35	BJ0035	VALVE STEM
36	BJ0036	O-RING
37	BJ0037	VALVE SPRING
38	BJ0038	DEFLECTOR
39	BJ0039	AIR INLET
40	BJ0040	HEXAGON WRENCH KEY 4
41	BJ0041	SCREW
42	BJ0042	IDLE PULLEY SCREW
43	BJ0043	WASHER
44	BJ0044	SCREW
45	BJ0045	SPRING WASHER
46	BJ0046	FINGER PAD ASSY
41A	BJ0041A	C-CLIPPER
48	BJ0048	LOCK
49	BJ0049	GUARD
50	BJ0050	SCREW (2)
51	BJ0051	PIN
		GUARD BODY ASSY. (Incl. 3, 5, 5A, 6, 8~17, 44~46,48~51)